

Stock Weight Instructions

CAUTION:

Please check careful the length of stock bolt coming through the head of the stock and screwing into the rear of the receiver. The screw should be no more than 8 threads, any more than this can damage the action. Less than 7 is insufficient thread to secure the stock.

If you do not have enough thread please remove one of the 6 disc springs.

If the stock bolt is too long add one or more disc springs from your original stock bolt.

Please note how these are positioned, concave to concave

The weights can be positioned anywhere on the top portion of the bolt. Further to the rear increases the apparent weight. The clamping screw uses a 2.5mm hex wrench. This is the same wrench used to adjust the comb on your K-80.



